Coffee Machine SKAD 1000 A1

GB IE **Coffee Machine**
Operating instructions

KOMPERNASS GMBH
BURGSTRASSE 21 · D-44867 BOCHUM
www.kompernass.com
ID-Nr.: SKAD1000A1-07/10-V3
IAN: 54348

1
2
3
4
5
6
7
8
9
10
11
SILVERCREST

Cleaning

To obtain an optimal taste result after every brewing process you should clean the coffee machine after every use.

- Unplug the power cable from the mains power socket.

⚠ *Risk of electric shock!*

Before you clean the coffee maker you MUST remove the plug from the mains power socket. Under no circumstances may the appliance be immersed in water or held under running water during cleaning.

⚠ *Risk of burns!*

Always wait until the coffee maker has cooled down before cleaning it. This avoids the potential risk of being burnt.

⚠ *Attention!*

Do not use household detergents or sharp/pointed objects to remove soiling. . These could damage the appliance.

- Wipe the housing of the coffee machine and the thermos can ❽ with a soft cloth lightly moistened with a soapy solution. At the same time remove any deposits that may have settled in the thermos can ❽.
- After every brewing process remove the filter bag from the filter holder ❹.
- Rinse both of them under running water.
- Clean the measuring spoon in mild soapy water and rinse it with clean water.

Scale removal

The mineral content (hardness) in the water causes, over a period of time, a calcification of the coffee machine. This calcification impairs the appliance in its function and diminishes the quality of the brewed filter coffee.

ⓘ *Note:*

Enquire at your local waterworks about the hardness level of your mains water. The need for decalcification comes early in hard water areas, somewhat later in soft water areas. Use a decalcifier designed for household appliances and pay heed to the usage instructions.

1. Switch the coffee machine off and allow it to cool down completely.
2. Place the scale removal product in the water tank ❷.
3. Fill it with the maximum permitted amount of water for descaling (see the descaler instructions). However, do not pour in more water than to the 8-cup marking in the water tank ❷.
4. Place the thermos can ❽ on the stand plate ❿.
5. Press the On/Off switch ❾.
6. Wait until the brewing process is complete and the control lamp goes out.
7. Unplug the power cable from the mains power socket.
8. Carefully rinse the thermos can ❽ with mains water.
9. Take the water tank ❷ off and rinse it out with clean water.
10. To finish, complete two brewing processes using only mains water, as described in the section "Before the first usage".

When completed, you can continue to use the coffee machine.

Troubleshooting

Symptom	Possible Cause and Remedy
The coffee machine does not switch on.	• The plug is not inserted into the power socket. Insert the plug into a power socket. • A domestic electrical fuse is defective. Check the fuses and replace them if necessary. • The mains power socket is defective. Try a different mains power socket. • The coffee machine is possibly defective. Arrange for the coffee machine to be checked over by specialists.
The quality of the brewed coffee is deteriorating.	• The coffee machine is calcified. Decalcify the coffee machine.
The coffee is too strong	• The aroma selector switch ❺ is incorrectly set. Turn it to the correct position. • Use less coffee.
The coffee is too mild	• The aroma selector switch ❺ is incorrectly set. Turn it to the correct position. • Use more coffee.

Storage

- If you do not intend to use the coffee machine for an extended period, clean it and dry it well.
- Slide the power cable into the cable shaft ⓫ at the rear of the machine and then secure the plug in the holes above the cable shaft ⓫.
- Store the appliance at a clean and dry location.

Disposal

Do NOT dispose of the appliance in your normal domestic waste. This product is subject to the provisions of European Directive 2002/96/EC.

Dispose of the appliance through an approved disposal centre or at your community waste facility. Observe the currently applicable regulations.
In case of doubt, please contact your waste disposal centre.

Dispose of all packaging materials in an environmentally friendly manner.

Technical data

Mains voltage: 220 - 240 V ~, 50 Hz
Nominal power: 1000 W
Filter bags: 1 x 4

Warranty and Service

You receive a 3-year warranty for this appliance as of the purchase date. This appliance has been manufactured with care and meticulously examined before delivery.
Please retain your receipt as proof of purchase. In the case of a warranty claim, please make contact by telephone with our Customer Service Department. Only in this way can a post-free despatch for your goods be assured.
The warranty covers only claims for material and manufacturing defects, not for transport damages, wearing parts or for damage to fragile components, e.g. buttons or batteries. This product is for private use only and is not intended for commercial applications.
In the event of misuse and improper handling, use of force and interference not carried out by our authorized service branch, the warranty will become void. Your statutory rights are not restricted in any way by this warranty.
The warranty period is not extended by repairs effected under warranty. This applies also to replaced and repaired parts. Damages or defects discovered after purchase are to be reported directly after unpacking, at the latest two days after the purchase date. Repairs carried out after lapse of the warranty period are subject to charge.

GB DES UK LTD
Tel.: 0871 5000 700 (£ 0.10 / minute)
E-Mail: support.uk@kompernass.com

IE Kompernass Service Ireland
Tel: 1850 930 412 (0,082 EUR/Min.)
Standard call rates apply. Mobile operators may vary.
E-Mail: support.ie@kompernass.com

Importer

KOMPERNASS GMBH
BURGSTRASSE 21
D-44867 BOCHUM, GERMANY

www.kompernass.com